



INSTRUCTION MANUAL VACUUM GATE VALVE WITH ROTARY ACTUATOR

INTRODUCTION


The uncomplicated design of these high vacuum gate valves makes servicing easier than on any other gate valve. The valves are welded from custom extrusions of aluminum. These extrusions have a very smooth and bright surface finish which is one of the reasons for the low out-gassing and fast pump down of these valves. Dismantling requires no training or practice, and reassembly errors are almost impossible. There is only one way to put any part or assembly in place and there are no critical adjustments. With one motion the entire internal mechanism is lifted from the valve while the flanged port section stays bolted in the system. The short body sections make cleaning easier and faster. The centerline body flange makes this possible and reduces maintenance and servicing time to a minimum.

The diagram inside shows the rotary seal principle and the no-contact-gate action. The gate (disc) O-ring seals in a motion perpendicular to its seat, without O-ring scuffing. The gate carriage assembly stays securely locked in position at the open or closed position because of the dead centers at the extremes of the 180° arc. The half circle swing of the cam is rapid at mid-way point, slowing to stop at top or bottom. This makes very fast action possible without the hammer effect of a plunger type operator. It is built-in cushioning for the stroke which means negligible wear and a long operating life without maintenance.

These valves will work equally well in any orientation. It should be determined that the valve and/or adjacent piping of the vacuum system will be adequately supported when assembled. Make certain the mating flanges are in-line, parallel and the correct distance apart to minimize the strain on the valve body. It is important to remember that the gate seal is on the operator or hub side of the valve on sizes 2" to 8". On sizes 10" and larger the operator is on the opposite, or open side.

These valves will hold vacuum in either direction. However, no gate valve will open easily in a vacuum-to-atmosphere condition with the pressure of atmosphere on the open side, or against the back of the gate. If opening is necessary with a vacuum to atmosphere differential, make sure the gate faces upstream (toward atmosphere or higher pressures) or install a means of equalizing pressure prior to actuation. Gate valves will not close easily against atmosphere if the vacuum side is a very large chamber where the inrush of atmosphere may approach very high velocity.

MAINTENANCE: These valves do not require any routine maintenance. However, it is necessary to prevent the accumulation of dirt and debris inside the valve and if your vacuum system is extremely dusty or dirty, cleaning the interior of the valve will be required from time to time. When the valve is disassembled for cleaning, it is recommended that the O-rings be replaced. Note that cleaning O-rings with solvents is never recommended, because the solvent will be absorbed by the O-ring and will produce high outgassing for hours or even weeks after such cleaning. If vacuum grease is used on O-rings, it can also cause outgassing and 'burps' of gas. Only a thin, almost invisible, coating of grease should be used on O-rings in vacuum systems. Flange O-rings shipped with new valves and O-rings shipped as spare or replacement parts have not been greased prior to shipment.



ELECTRO PNEUMATIC (EP) ACTUATORS:

The 'EP' actuators include a 4-way solenoid valve actuator with 24" leads and are mounted, ready for wiring when valves are ordered for pneumatic operation. The one side of the solenoid bracket (stamped "C") is normally closed. The other side (stamped "D") is normally open. The "C" side Opens the gate valve; the "D" side closes it. Recommended minimum air pressure is 65 psi (4.6 kg/cm²) for valves with 2 inch and 3 inch ANSI flanges (NW-50 to ISO 80). Recommended minimum air pressure for valves with 6 inch to 16 inch ANSI flanges (ISO 100 to ISO 400) is 85 psi. (6 kg/cm²). Recommended maximum air pressure for all sizes is 100 psi. (7 kg/cm²).

NOTICE


If valve is to be opened with a pressure differential of 50 Torr or more it must be installed with the open side toward the pump and the seal side facing the chamber or furnace (Higher Pressure).



WARNING

The air supplied to these valves must be free of oil, water and dirt for proper operation. If the air at your facility is not clean and dry you must install filters and traps upstream of the valve.

Wiring: The preferred method to preclude human error, employs SPST switches as in Fig. 1. Connect two wire leads to source with a SPST toggle switch in either line. When solenoid is energized, valve opens; when solenoid is de-energized, valve closes. Pressure remains in cylinder.



FAIL-SAFE: When connected this way, the valve will automatically close if power fails. To provide for manual operation during failure, a shut-off and a vent valve must be put in the air line to bleed off high pressure air in the cylinder. You can then operate the valve manually by turning the hex nut on stem with a wrench. With on/off switches, valves will open when power returns unless switched to "off" before power comes on.


SPARE PARTS FOR 'LPWA' ALUMINUM VALVES

	LPWA 2 & 3 Built Sept. 2005 and Later ISO-100 ANY DATE	LPWA-4 ISO-160		LPWA-6 & LPWA-8 ISO-200		LPWA-10 & LPWA-12 ISO-250 & 320 For Valves With Extruded Bodies (Sept. 01 & Later)		LPWA-10 & LPWA-12 ISO-250 & 320 For Valves With Bodies Fabricated From Plates (Aug. 01 & Before)		LPWA-16 ISO-400	
	Price P/N	Price	P/N	Price	P/N	Price	P/N	Price	P/N	Price	P/N
	\$86.00	\$ 86.00		\$144.00		\$144.00		\$144.00		\$231.00	
11.00 X810604B No Centering Rings		\$23.00 X701WA400B		\$ 42.00 X701WA600B (6") \$ 42.00 X701WA800B (8")		\$ 59.00 X701WA1000BR1 (10") \$ 62.00 X701WA1200BR1 (12")		\$ 59.00 X701WA1000B (10") \$ 62.00 X701WA1200B (12")		\$62.00 X810394 BUNA N	
46.00 X810604V No Centering Rings		\$82.00 X701WA400V		\$120.00 X701WA600V (6") \$120.00 X701WA800V (8")		\$143.00 X701WA1000VR1 (10") \$146.00 X701WA1200VR1 (12")		\$143.00 X701WA1000V (10") \$146.00 X701WA1200V (12")		\$159.00 X810395 VITON	
29.00 X701201B		\$29.00 X701401B		\$ 29.00 X701401B		NA		\$ 40.00 X7011001B		NA	
29.00 X701204B		\$29.00 X701404B		\$ 29.00 X701404B		\$ 40.00 X7011004B		\$ 40.00 X7011004B		\$106.00 X810396	
200.00		323.00		455.00		1287.00		1287.00		CONTACT FACTORY	
If roughing ports are required specify as R1-NW-16 etc. as described in the Valve Catalog and add the cost to the bonnet section prices shown above.											
	LPWA ISO 100	LPWA-4	LPWA-6	LPWA-8	LPWA-10	LPWA-12	LPWA-10	LPWA-12	CONTACT FACTORY		
	363.00	427.00	750.00	1233.00	1489.00	1725.00	1489.00	1725.00			
	398.00	507.00	837.00	1258.00	1604.00	1841.00	1604.00	1841.00			
	398.00	507.00	837.00	1258.00	1604.00	1841.00	1604.00	1841.00			
	444.00	594.00	940.00	1298.00	1720.00	1956.00	1720.00	1956.00			
	LPWA ISO 100	LPWA-4	LPWA-6 & LPWA-8		LPWA-10 & LPWA-12		LPWA-10 & LPWA-12		LPWA-16 & ISO-400		
	335.00 X810084	362.00 X706203rev2	481.00 X706303rev2		1009.00 X810439		1009.00 X810507		3650.00 X810624		
	87.00 X806500	87.00 X806500	87.00 X806500		363.00 X806502		363.00 X806502		524.00 X810397		
	15.00 X706102	15.00 X706202	22.00 X706302		34.00 X810536		34.00 X810536		100.00 X810398		
	25.00 X706108 LIST	22.00 X706108	22.00 X706108		52.00 X706408		52.00 X706408		265.00 X810635		
	7.00 X706256	7.00 X706206	16.00 X706306		22.00 X706406		22.00 X706406		54.00 X810636		
	44.00 X706110rev1	44.00 X706110rev1	44.00 X706110rev1		121.00 X706410rev1		121.00 X706410rev1		121.00 X810637		
	2.00 X706105	2.00 X706205	2.00 X706205rev1		3.00 X706405rev1		3.00 X706405rev1		149.00 X810638		
	1.00 X706119	1.00 X706119	1.00 X706119		1.00 X706419		1.00 X706419		8.00 X810639		
	1.00 X706119	1.00 X706119	1.00 X706119		1.00 X706419		1.00 X706419		6.00 X810640		
	103.00 X700051	129.00 X04WA116	161.00 X406116		403.00 X700269		403.00 X10WA116		1031.00 ea X700206		
	103.00 X700270	104.00 X04LP117rev1	110.00 X06LP117rev1		346.00 X700285		346.00 X10WA117		1143.00 X740057		
	151.00 X810657	111.00 X706216rev2	129.00 X706316rev2		258.00 X706WA416		258.00 X706WA416		313.00 X810641		
	96.00 X706WA117	121.00 X706WA210	149.00 X706WA317		176.00 X706WA417		176.00 X706WA417		296.00 X810642		
	14.00 X02LP108A	21.00 X04LP108A	21.00 X04LP108A		26.00 X10LP108A		26.00 X10LP108A		52.00 X810643		
	80.00 X02WA118	92.00 X04WA118	110.00 X06WA118		140.00 X10WA118		140.00 X10WA118		259.00 X810644		
	1.00 X702176	1.00 X702177	1.00 X702177		1.00 X702177		1.00 X702177		NA		
	11.00 X706118	11.00 X706318	11.00 X706318		17.00 X706418		17.00 X706418		86.00 X810645		
	17.00 X706118V	20.00 X706318V	20.00 X706318V		29.00 X706418V		29.00 X706418V		78.00 X810646		
	70.00 X706112rev1	70.00 X706312rev2	70.00 X706312rev1		70.00 X706412rev1		70.00 X706412rev1		149.00 X810647		
	11.00 1/4-20X1(6)	11.00 1/4-20X1 1/4(6)	16.00 1/4-20X1 1/4(14)		19.00 1/4-20X1 3/4(16)		19.00 1/4-20X1 3/4(16)		18.00 3/8-16X2(12)		
	317.00 X810089	363.00 X806204rev1	363.00 X806304rev2		663.00 X806404rev3		663.00 X806404rev2		2,193.00 X810648		
	138.00 X02LP200	138.00 X04LP200	138.00 X06LP200		241.00 X10LP200rev2		241.00 X10LP200rev1		335.00 X810649		
	42.00 X706114	42.00 X706214	42.00 X706314		59.00 X706414rev1		59.00 X706414		66.00 X810650		
	45.00 X706126	45.00 X706226	54.00 X706326		91.00 X706426rev1		91.00 X706426		190.00 X810651		
	96.00 X706131	112.00 X706231	112.00 X706231		112.00 X706431rev1		112.00 X706431rev1		286.00 X810652		
	15.00 X701101	15.00 X701101	15.00 X701101		30.00 X701101		30.00 X701101		30.00 X810653		
	20.00 X02LP150	20.00 X04LP150	20.00 X06LP150		30.00 X700337		30.00 X10LP150		83.00 X700581		
	47.00 X706132	53.00 X706232	53.00 X706232		83.00 X706432		83.00 X706432		415.00 X810654		
	21.00 X706130	26.00 X706230	26.00 X706330		37.00 X706430rev1		37.00 X706430		67.00 X810655		
	80.00 X703042	104.00 X04WA152	121.00 X06WA152		144.00 X700284		144.00 X10WA152		392.00 X700545		
	19.00 X02LP202	19.00 X04LP202	19.00 X06LP202		24.00 X10LP202		24.00 X10LP202		37.00 X700569		
	3.00 X02LP203	3.00 X04LP203	3.00 X06LP203		3.00 X04LP203		3.00 X04LP203		6.00 X700568		
	1.00 X702170	1.00 X702171	1.00 X702171		1.00 X702172		1.00 X702172		4.00 X702092		
	92.00 X134010 -220VAC	92.00 X134010 -220VAC	92.00 X134010 -220VAC		92.00 X134010 -220VAC		92.00 X134010 -220VAC		129.00 X134019		
	92.00 X703005 -115VAC	92.00 X703005 -115VAC	92.00 X703005 -115VAC		92.00 X703005 -115VAC		92.00 X703005 -115VAC		129.00 X134012		
	92.00 X703031 - 24VDC	92.00 X703031 - 24VDC	92.00 X703031 - 24VDC		92.00 X703031 - 24VDC		92.00 X703031 - 24VDC		129.00 X134016		
	140.00 X706094	140.00 X706094	140.00 X706094		140.00 X706094		140.00 X706094		177.00 X810656		

! WARNING !

Disconnect electrical & air supply before making any adjustment or repairs.

PNEUMATIC OPERATOR ADJUSTMENT:



(1) Be sure that the air and power lines are disconnected. (2) This alignment procedure requires the valve to be completely assembled with gate carriage installed and the port and bonnet bolted together. (3) If your valve is equipped with position indicator switches remove them by removing the 3 screws that hold the switch bracket to the EP mounting bracket. Remove the protective EP cover so that the actuator cylinder and gears are visible. (4) Using a wrench rotate the hex nut clockwise to move the cylinder (9F) to the full closed position. (Far right side, see the label on the air cylinder.) Remove the E clip, hex nut, key, and top guide washer and pull the pinion gear off of the valve stem (Part No. 4). (5) After the pinion is removed, move the cylinder back toward the open position by the space of approximately 1/2 or 1 full gear tooth. (6) Now replace the pinion on the stem and engage it with the rack without moving the cylinder. Re-install the top guide washer, hex nut, key, and E-clip on the stem. (7) To ensure that rack and pinion properly engage without binding or skipping teeth you may tap lightly on the EP brackets to move the rack closer or farther from the pinion. (8) Be sure that all bolts on EP bracket are tight (Part No. 9D). (9) Reconnect electrical and air supply. (10) Operate valve and listen for gate locking in closed position.

DISASSEMBLY: With valve in open position, remove centerline body flange bolts and lift the bonnet section free. The entire internal mechanism comes free with this one motion. Then turn the manual lever, or the hex nut above the pinion gear on pneumatic valves, to release the carriage from its locked position. Pull on carriage and it will come out and slide off the crank roller. The flanged section stays bolted in the system unless the gate seat is damaged and needs polishing or machining. When the stem seal area is also to be cleaned or needs new seals, the steps are easy: (1) Take off manual lever or pinion gear. (2) Use appropriate snap ring pliers to remove retaining ring 9-r and remove the gland spacer (5-a1) and hub flange screws. (3) Lift out hub by sliding over stem, which will bring stem seal assembly with it, which can then be lifted out with a finger. (4) The stem crank comes out easily through the centerline flange opening.

ASSEMBLY: Apply a very thin film of vacuum grease to the shaft and: (1) Grasp the stem crank by the roller end, tip the stem to the side, insert in the bonnet flange opening and bring the stem out through the hub opening. (2) Place hub O-ring seal in hub flange and slide hub onto stem while holding stem-crank up to make it easy to insert. (3) Replace and tighten the 1/4-20 hub flange screws evenly. (4) While holding the stem crank up with one hand and pushing to the farthest point through the stem housing in the hub, insert the stem seal assembly and be sure of the proper order. Slide over stem first, one O-ring; next, a washer. Then slide the spring over the stem; next a washer, and last, the second O-ring. Make sure this second O-ring is down over the shoulder on the stem. (5) While still holding up the stem, replace the stem gland spacer (push downward to overcome spring tension). Hold the internal retaining ring 5-C in position and seat it in the modified hub groove using appropriate snap ring pliers. (6) Replace manual lever or pinion gear of pneumatic operator with key in its slot. Retaining ring 9-r fits onto the stem crank. (7) Insert gate seal evenly, and with crank turned to expose its roller, slide carriage slot overroller and retract into bonnet by turning stem counterclockwise (with manual lever or a wrench on pinion head nut). (8) Insert body flange seal evenly and position the bonnet assembly on the flanged section—Gate toward its seat, with locator pins lined up with holes. (9) Replace and evenly tighten body bolts in centerline flanges.

! WARNING !

A valve wired to automatically close on power failure will also automatically open when power is restored. This reopening may be unsafe, and it is recommended that a latching relay be installed so that the valve will not just automatically reopen when power is restored, but will remain closed until an operator decides it is safe to reopen.

CONVERTING FROM MANUAL TO ELECTROPNEUMATIC (EP) OPERATOR: Operators for conversion of manual valves are factory assembled, aligned and tested before shipment, with piston shafts tight to brackets. Simply tighten brackets to valve body, with “D” bracket on the “closed” side—to the right as you look at the face of the valve, with centerline flange down. If operators are removed from pneumatic valves, it is generally unnecessary to disassemble them. Leave the shaft tightened to brackets for easiest reassembly. With cylinder in place, brackets tightened, replace pinion gear parts on the stem in this order: (1) bronze thrust washer, (2) gear washer without key slot, (3) pinion gear, (4) key, (5) gear washer with key slot, (6) hex nut, (7) retaining ring. When placing pinion gear, engage the nearest rack tooth with it, with cylinder at farthest right, toward the “closed” side, and stem and gear key slots aligned. Slight movement of the cylinder may help to align key slots when inserting key (as in 4). Then proceed with (4) through (7). Secure solenoid actuator to the valve body, with “C” and “D” sides matching “C” and “D” on cylinder. Install air lines and tighten fittings, “C” with “C” and “D” with “D”.

